



Versandanschrift
 Address
 Adresse du destinataire
 Indirizzo di trasporto
 Dirección de expedición

Fax.-No

Ersatzteilliste
Spare parts list
Liste des pièces de rechange
Elenco parti di ricambio
Lista de piezas de repuesto

1440205

6.2 bar

TruTool
F 125 (1A2)

NO	BEST.-NR.	PEZZO DI RICAMBIO PIEZA DE RECAMBIO PIECE DE RECHANGE SPARE PART ERSATZTEIL	DIN	QUAN. CANT. QUAN. QUAN. STK.
1	0021105	9X1-FDST	DIN471	
2	0021440	26X1,2-FDST	DIN472	
3	0027740	6000-Z	DIN625	
4	0012246	3X3X8-Ck45	DIN6885	
5	0004391			
6	0027162	K12x15x13		
7	0004331			
8	0027685	609.2RSR	DIN625	
9	0102537			
10	0014605	M5X35-12.9	DIN912	
13	0004336			
14	0004368			
15	0021091	8x0.8-FDST	DIN471	
16	0102920			
23	0105889	M8X35-8.8	DIN6912	
28	0027693	625	DIN625	
29	0102437	HK0509		

30	0010090	4m6X12	ISO2338	
31	1440549			
32	1440953			
33	1438670			
41	0105449			
42	0102962			
43	0102963			
44	0096612	bis 12/95		
45	0102919			
46	0105835			
47	0102964			
48	0102965			
49	0102967			
50	0105448			
76	0096690	NBR 70,5/P5		
80	0088370	ORM 0120-20		
81	0103199	5X35	DIN1473	
91	0028459			
92	0112633			
93	0028457			
94	0112637	Incl. 92, 93		

