



Versandanschrift
 Address
 Adresse du destinataire
 Indirizzo di trasporto
 Dirección de expedición

Fax.-No

Ersatzteilliste
 Spare parts list
 Liste des pièces de rechange
 Elenco parti di ricambio
 Lista de piezas de repuesto

1440211	6.2 bar
TruTool	
N 200 (1A2)	

NO.	D'ORDINE NO. DE REF.	PEZZO DI RICAMBIO PIEZA DE RECAMBIO PIECE DE RECHANGE SPARE PART ERSATZTEIL	DIN	QUAN. CANT. QUAN. QUAN. STK.
1	0014591	M5X30	DIN912	2
2	0945993			1
3	0089021	629.2RSR	DIN625	1
4	0085103	NK5/10TN	DIN617	1
5	0085120			1
6	0085928			1
7	0085111	K14X18X13	DIN5405	1
8	0028457			1
9	0112633			1
10	0033313			1
11	0027693		DIN625	1
12	0012246			1
13	0026190	6200-Z	DIN625	1
14	0021466	30x1.2-FDST	DIN472	1
15	0028459			1
16	0021105	9x1-FDST	DIN471	1
17	0343753			2
18	0954203			1
19	0343577	M5X8	DIN7500	1

20	0954822			1
21	0945663			1
22	0945668			1
23	0945665			1
24	0345192			4
25	0945666			4
26	0970585			1
27	0345080			4
31	0090799			4
33	0949147			1
34	0945669			1
35	0131214			1
38	0944506			1
39	0964616	incl. 33+34+35		1
40	0945692			1
41	0980335	incl. 42+43		1
42	0966729			1
43	0966453			1
44	0112637	No. 8+9		1
45	0010073	4m6X8	ISO2338	1
46	1440549			2
47	1440958			1
48	1438671			1

