



Ersatzteilliste	F 140 (1B1)	F 140 (1C1)	TruTool F 140 (1B1) (1C1)		
Spare parts list	1274397	1274398		D	230V 50Hz
Liste des pièces de rechange	1283462	1283463		CH	230V 50Hz
Elenco parti di ricambio	1283464	1283465		GB	110V 50Hz
Lista de piezas de repuesto	1283470	1283471		USA	120V 50/60Hz

订货号 备件			44	0003526	
No. D'ORDINE	PEZZO DI RICAMBIO		45	0023698	8x14x0.3 St50K
NO. DE REF.	PIEZA DE RECAMBIO		46	0027251	HK 0808 DIN 988
NO. DE REF.	PIECE DE RECHANGE		47	0021440	26x1.2-FDST
ORDER NO.	SPARE PART		48	0035772	DIN 472
NO BEST.-NR.	ERSATZTEIL		49	0012238	3x3x6-St50K
			51	0035756	DIN 6885
3	0003523	F 140 (1B1)	52	0010677	4m6x14 St60
	1237113	F 140 (1C1)	53	0018074	M4x20-10.9 DIN 6885
4	0012254	3x3x10-St50K DIN 6885	54	0027693	DIN 7991
5	0027260	HK 1414-RS	55	0096094	DIN 625
8	0018740	M3.5x22 DIN 84	56	0016527	M5x6h8x10
9	0035758		57	0096087	mm ISO 7379
19	0003519		58	0096088	mm ALU
20	0021091	8x0.8-FDST DIN 471	59	0096089	GA
21	0011622	6x20-FDST DIN1481	60	0096090	GA ALU
22	0028390		61	0102200	
23	0028389				
24	0012173	M6x22-12.9 DIN 912	90	0105084	
25	0003514		92	0035395	
26	0011037	12m6x55 DIN 6325	93	0035770	
27	0003522		94	0028458	
28	0027740	6000-Z DIN 625	136	0018139	
29	0003528				
30	0021113	10x1-FDST DIN 471	200	1257531	
31	0003525		201	0116024	M4x10-ST-8.8 ISO 4762
32	0003527		202	1658997	
33	0003515		203	0014451	M4x22-ST-12.9 ISO 4762
35	0096092		204	1237019	
36	0013269	M8x20-45H DIN 913	205	0011452	4x18-FDST ISO 8748
37	0029173		206	1237020	
38	0013846	M5x8-45H DIN 914	207	1243792	
39	0003516		208	0113038	
40	0019526	M5x12-12.9 ISO 7380			
41	0003529				
42	0021474	32x1.2-FDST DIN 472			
43	0027804	6002-Z DIN 625			

